

Pasarela

Footbridge

Technical file



SPARE PARTS



CUSTOMIZABLE



RECYCLED
MATERIAL



RECYCLABLE

Description

Frame

Made of polypropylene resin.

Reinforced with mineral filler and a special formulation with UV treatment.

Security

Non-slip surface.

There is no risk of injury to the user due to the appearance of cracks or splinters, as is common with wooden walkways.

Product suitable for users with reduced mobility or in wheelchairs.

Pasarela

Footbridge

Capacity



A - 120 cm
B - 25 cm
C - 5 cm
D - 25 cm

4,5 kg


| Package | Units | Measures | Weight | Volume |
|---------|---------------|----------------|--------|---------------------|
| Box | 4 u. (1 m.) | 120x100x5 cm | 18 kg | 0,06 m ³ |
| Pallet | 55 u. (22 m.) | 120x107x125 cm | 410 kg | 1,60 m ³ |

| Loading capacity | Mega trailer | Cont. 20' | Cont. 40' | Cont. 40' High Cube |
|------------------|------------------------|----------------------|----------------------|----------------------|
| Pasarela | 4.224 u. (1.056 m.) | 1.512 u. (378 m.) | 3.024 u. (756 m.) | 3.696 u. (924 m.) |

Finishes

Frame

Resin





Pasarela

Footbridge

Maintenance plan

Monthly

Check the parts that make up the walkway are joined correctly.

Annual

Check the good condition of the product.

Replace parts that may be in poor condition.

Wintering and storage

Clean with soapy water and a soft cloth.

Remove damp stains, sand and seawater.

Store horizontally in a dry place.

Observations

- Always use Balliu spare parts.
- Balliu does not manufacture parts for other brands.
- If the product is subject to heavy use, maintenance checks must be carried out more frequently.
- Do not use the product until maintenance is completed.
- Do not use aggressive chemicals to clean the product.
- Always use products with a neutral pH.
- Use a soft cloth to clean the product.

