

Etna

High chair

Technical file



FABRIC



STACKABLE



SPARE PARTS



CUSTOMIZABLE



RECYCLABLE

Description

Frame

Manufactured with a 1,5 mm thick 6063-20 aluminum alloy profile.

Screws

Manufactured in AISI 304 stainless steel that offers great resistance to corrosion in marine environments.

Paint

Powder paint based on polyester resins that offers great resistance to light and outdoor environments in accordance with QUALICOAT international specifications and ISO-2409 and ISO-2360 regulations.

Fabric

Breathable fabric constructed with double weft and double warp, 1.25 mm thick and 870 g/m² density. Made of a continuous polyester thread core (30%) coated with PVC (70%).

Resistant to UV rays, with a light resistance index of 8.

Antimicrobial protection that protects against bad odors and moisture.

Fire resistance due to flammability retardant according to EN-1021-2:2015 regulations.

Accessories


Caps and studs made of polypropylene resin resistant to UV rays.



Etna

High chair

Capacity



A - 56 cm
B - 100 cm

C - 53 cm
D - 64 cm

3,7 kg

Package	Units	Measures	Weight	Volume
Pallet	10 u.	70x124x158 cm	52 kg	1,37 m ³

Loading capacity	Mega trailer	Cont. 20'	Cont. 40'	Cont. 40' High Cube
Etna	1.196 u.	460 u.	1.012 u.	1.012 u.

Finishes

Frame

Matte texture




White

Aluminum Turtledove

Fabric

Basic





Etna

High chair

Maintenance plan

Weekly

Visual check of the general condition, removing dirt and ensuring there are no broken parts or damage that could be a danger to users.

Monthly

Check fabric tension.
Check that the aluminum structure has no damage or deep scratches.
Check the structural strength and stability.
Check the condition of the caps and studs.

Annual

Check the condition of the fabric and ensure it is correctly tensed.
Repair any damage to the paint.
Replace any worn or damaged parts.

Wintering and storage

Clean with soapy water and a soft cloth.
Remove damp stains, sand and seawater.
Store horizontally in a dry place in stacks of 6 units.

Observations

- Always use Balliu spare parts.
- Balliu does not manufacture parts for other brands.
- If the product is subject to heavy use, maintenance checks must be carried out more frequently.
- Do not use the product until maintenance is completed.
- Consult the maintenance instructions.
- Do not use aggressive chemicals to clean the product.
- Always use products with a neutral pH.
- Use a soft cloth to clean the product.

